


**ELISE 100 INDUCTION**

DATE 15.04.2019

**DSL0767 P00**

ISSUE STATUS 01






**HOB AND INDUCTION ASSEMBLY**


**ELISE 100 INDUCTION**


DATE 12.04.2019 ISSUE STATUS 01

**DSL0767 P03**



**CONTROLS ASSEMBLY**





GRILL CHAMBER


**ELISE 100 INDUCTION**

DATE: 22.03.2019

**DSL0767 P05**

**FROM SERIAL NUMBER: 203000**

ISSUE: 01




**LEFT HAND OVEN (FANNED & LIGHT)**


**ELISE 100 INDUCTION**

DATE 30.11.17

**DSL0767 P06**  
ISSUE STATUS 01



**RH OVEN**




COOKER CHASSIS




**ELISE 100 INDUCTION**  
FROM SERIAL NUMBER 171000

DATE 24.02.14


**DSL0767 P09**  
ISSUE STATUS 02




**CHASSIS AND FRAME ASSEMBLY**




**CHASSIS ACCESSORIES**





GRILL DOOR




# ELISE 100 INDUCTION


# DSL0767 P13


ISSUE STATUS 01

DATE 25.03.2019



## RH OVEN DOOR





Code	Description
b	Blue
br	Brown
bk	Black
or	Orange
r	Red
v	Violet
w	White
y	Yellow
g/y	Green / Yellow

Code	Description
A1	Grill Front Switch
A2	Grill Energy Regulator
A3	Grill Element LH / RH
B1	LH oven Thermostat Switch
B2	LH oven Thermostat
B3	LH oven top element (Outer)
B4	LH oven top element (Inner)
B5	LH fan element
B6	LH oven base element
B7	LH oven fan
B8	LH oven Switch
D1	RH oven front switch
D2	RH oven t/stat
D3	RH oven fan element
D4	RH oven fan
F1	Oven Light Switch
F2	LH Oven Light
G	Neon
H	Oven Thermal Preset
I	Cooling Fan
C	Inline Connector
TB	Internal Terminal Block