

314

302

302

310

309

311

303

304

305

308

307

312

313

315

306


306


312


304

302


INNER CONTROL PANEL
(SHOWN FOR REF ONLY)








FROM SERIAL NUMBER 174000
UP TO SERIAL NUMBER 181999



LH OVEN
(MULTI - LIGHT)



LH 'FLAT' OVEN
(MULTI - LIGHT)
FROM SERIAL NUMBER 182000


ELISE 110 INDUCTION (G5)

DATE 16.01.14

DSL0520 P07

UP TO SERIAL NUMBER 173999


ISSUE STATUS 02




RH OVEN


FROM SERIAL NUMBER 174000
UP TO SERIAL NUMBER 181999


- 762 OVEN Baffle
- 760 FIXING SCREWS
- 763 LAMP HOLDER
- 764 FIXING SCREWS




RH OVEN
(FAN - LIGHT)











ELISE 110 INDUCTION (G5)

DATE 02.04.15

DSL0520 P11

ISSUE STATUS 02





FROM SERIAL NUMBER 182000

