


ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P00






**PAN SUPPORTS
BURNERS & HOTPLATE ASSEMBLY**

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P02




GAS RAIL - TAPS - INJECTORS AND PIPES

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P03




CONTROLS

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P03A




FACIA - CONTROL KNOBS AND PLINTH

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P04




GRILL CHAMBER

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P05




LEFT HAND OVEN (FANNED & LIGHT)

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P06




RH OVEN

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P08




COOKER CHASSIS

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P09




CHASSIS AND INFILL PLATE

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P10




ACCESSORIES

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P11




GRILL DOOR

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P12




LH OVEN DOOR

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P13




RH OVEN DOOR

ELISE 90 DUAL FUEL
FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P14




ACCESSORIES AND SIDE PANEL

ELISE 90 DUAL FUEL FROM SERIAL NUMBER 203000

DATE: 02.12.2019

ISSUE: 01

DSL0770 P15



Code	Description
X01	Grill Front Switch
X02	Grill Energy Controller
X03	Left Hand Grill Elements
X04	Right Hand Grill Elements
X05	Left Hand Oven Thermostat
X06	Left Hand Oven Switch
X08	Left Hand Oven Base Element
X09	Left Hand Oven Fan Element
X10	Left Hand Oven Top Outer Element
X11	Left Hand Oven Top Inner Element
X12	Right Hand Oven Thermostat
X14	Right Hand Oven Front Switch
X15	Right Hand Oven Fan Element
X16	Oven Fan
X24	Cooling Fan
X26	Neon
X27	Thermal Cut-Out
X28	Ignition Switches
X30	Spark Generator
X31	Oven Light
X32	Oven Light Switch

Code	Description	Code	Description
b	Blue	v	Violet
br	Brown	w	White
bk	Black	y	Yellow
or	Orange	g/y	Green / Yellow
r	Red		

WIRING DIAGRAM