




OVEN DOOR LH





OVEN DOOR RH





Key	Ref Number	Part Number	Quantity	Remarks
865	h1	P050733	1	Wire Assy - LH Oven
866	h2	P037473	1	Wire Assy - MF Neon/Stat/Switch
875	w3	P033669	2	Wire - Cut-out Link Wire
881	NI	P037475	1	Wire (NI) - MF Oven Earth Wire
867	h4	P035499	1	Wire - LH Oven Element Link
876	w5	P033667	1	Wire - Lights/Neutral Wiring
868	h6	P037474	1	Wire Assy - Cooling Fan
882	NI	P033678	1	Wire (NI) - Earth RH T'Stat
869	h7	P050732	1	Wire Assy - RH Oven
883	NI	P033676	1	Wire (NI) - Earth RH Oven
877	w8	P037491	1	Wire - MF T'Stat to Switch Link
870	h9	P033680	1	Wire Assy - Ignition Switches L1
871	h10	P033679	1	Wire Assy - Ignition Switches L2
878	w11	P048632	2	Wire - Yellow Link
884	NI	P027413	3	6.3 Male In-line Connector
879	w12	P041537	1	Wire - 2 into 1 Female to Double Wire
872	h13	P095565	1	Wire Assy - MF Neon
873	h14	P036115	1	Wire Assy - MF Neon
874	h15	P049242	1	Wire Assy - HT Harness
880	w16	P049292	1	Wire Assy - HT Wire (LH Bumer)

NI Not Illustrated

w - Single Cable / Single Cable with multiple terminations

h - Harness Assembly (Including Single Wires that are Sheathed)

Code	Description
A1	Left-hand MF oven thermostat
A2	Left-hand MF oven control switch
A3	Left-hand MF oven base element
A4	Left-hand MF top element (outer)
A5	Left-hand MF browning element
A6	Left-hand MF oven fan element
A7	Left-hand MF oven fan
B1	Right-hand fan oven thermostat
B2	Right-hand fan oven control
B3	Right-hand fan oven element
B4	Right-hand oven fan

Code	Description
C1	Oven light switch
C2	Oven lamp
D1	Ignition switch
D2	Ignition spark generator
F	Cooling fan
G	Neon indicator
H	Thermal cut-out

Code	Colour
b	Blue
br	Brown
bk	Black
or	Orange
r	red
v	violet
w	White
y	yellow
g/y	Green/yellow
gr	Grey