

APPLIANCE NAME:
KITCHENER 90 CERAMIC UK

DATE 02.04.2019


DSL0763 P00
ISSUE STATUS 01





ALL KITCHENER 90 CERAMIC
FROM SERIAL NUMBER 203000

DATE 02.04.2019



ISSUE STATUS 01 DSL0763 P01




HOB AND CERAMIC ASSEMBLY



HOB AND CERAMIC ASSEMBLY



FACIA - CONTROLS - KNOBS




GRILL CHAMBER

**KITCHENER 90 CERAMIC
FROM SERIAL NO. 203000**

DATE: 02.04.2019

DSL0763 P05
ISSUE: 01




LEFT HAND OVEN (FANNED & LIGHT)


Kitchener 90 CERAMIC

DATE 02.04.19 ISSUE 01

DSL0763 P06



RH OVEN
FROM SERIAL NUMBER 203000




CHASSIS AND BACK

KITCHENER 90 CERAMIC
FROM SERIAL NUMBER 203000

DSL0763 P09A

ISSUE STATUS 01

DATE 26.03.2019




RH OVEN DOOR AND INFILL

Kitchener 90 Ceramic

DATE 01.04.19

DSL0763 P10


ISSUE STATUS 01




OVEN ACCESSORIES

KITCHENER

DSL0763 P10




PLINTH



GRILL DOOR

Kitchener 90 Ceramic

DSL0763 P12
DATE 02.04.2019 ISSUE STATUS 01




LH OVEN DOOR

KITCHENER 90 CERAMIC

DSL0763 P13

DATE 02.04.2019
ISSUE STATUS 001




RH OVEN DOOR

Kitchener 90 CERAMIC


DSL0763 P13

DATE: 02.04.2019



Code	Description
b	Blue
br	Brown
bk	Black
or	Orange
r	Red
v	Violet
w	White
y	Yellow
g/y	Green / Yellow

Code	Description
A	Left Ceramic Front Control
B	Left Back Ceramic Control
C	Centre right hand rear control
D	Centre right hand front control
F	Right Hand control
G	Hob Neons




HOB WIRING

Kitchener 90 CERAMIC

DSL0763 P13

DATE: 02.04.2019



Code	Description
b	Blue
br	Brown
bk	Black
or	Orange
r	Red
v	Violet
w	White
y	Yellow
g/y	Green / Yellow

Code	Description
A1	Grill Energy Regulator
A2	Grill Front Switch
A3	Grill Elements
B1	Left Hand Oven Thermostat
B2	Left Hand Oven Switch
B3	Left Hand Oven Element
B4	Left Hand Oven Fan
C1	Right Hand Oven Thermostat
C2	Right Hand Oven Front Switch
C3	Right Hand Oven Fan Element
C4	Right Hand Oven Fan
D	Clock / Timer
F	Cooling Fan
G1	Oven Light Switch
G2	Oven Light
H	Thermal Cut-Out
J1	Grill Neon
J2	Left Hand Oven Neon
J3	Right Hand Oven Neon

HOB WIRING