


GRILL CHAMBER ASSEMBLY

FALCON / RANGEMASTER  
PROFESSIONAL PLUS 110 INDUCTION

DATE 01.11.17

DSL0673 P04  
ISSUE STATUS 01




LEFT HAND 'FLAT' OVEN  
(ZONE - LIGHT)


**FALCON / RANGEMASTER  
PROFESSIONAL PLUS 110 INDUCTION**

DATE 01.11.17


**DSL0673 P05**  
ISSUE STATUS 01



**RH 'FLAT' OVEN  
(FAN - LIGHT)**




LEFT HAND OVEN DOOR ASSEMBLY




RIGHT HAND OVEN DOOR ASSEMBLY






STORAGE DRAWER ASSEMBLY



**FALCON / RANGEMASTER  
PROFESSIONAL PLUS 110 INDUCTION**

DATE 01.11.17

**DSL0673 P10**  
ISSUE STATUS 01




**COOKER CHASSIS  
& SIDE PANEL ASSEMBLY**


**FALCON / RANGEMASTER  
PROFESSIONAL PLUS 110 INDUCTION**


DATE 01.11.17

**DSL0673 P11**  
ISSUE STATUS 01



**COOKER BACK  
& ELECTRICAL**





Ref No.	Part No.	Colour	Description	Quantity	Remarks
w1	P037863	y	WIRE ASSEMBLY	2	YELLOW LINK
w2	P064457	v	WIRE ASSY	1	LH OVEN NEON LINK
w3	P049233	bk	WIRE ASSEMBLY	1	BLACK WIRE - RH OVEN SWITCH TIMER LINK
w4	P040066	b	WIRE ASSEMBLY	1	NUTRAL LINK - RH OVEN
w5	P025995	b	WIRE ASSEMBLY	1	NEUTRAL LINK RH OVEN - THREE LINKS
w6	P040694	b	WIRE ASSEMBLY	1	LH OVEN NEUTRAL DAISY LINK
w7	P043965	b	WIRE ASSEMBLY	1	WIRE 2 LINK RETURN LH OVEN
w8	P045407	v	WIRE ASSEMBLY	1	WIRE TIMER RELAY TO RH OVEN
h1	P064445	br, b, bk, r, v	HARNES - GRILL	1	-
h2	P064454	br, or, y	HARNES - FANNED OVEN	1	RH OVEN
h3	P066163	v, r	HARNES - COOLING/ZONED	1	-
h4	P064451	w, br, y	HARNES - LH ZONED OVEN	1	-
h5	P065632	b, br, bk	HARNES - AUX	1	-

Code	Colour
b	Blue
br	Brown
bk	Black
or	Orange
r	Red
v	Violet
w	White
y	Yellow
gly	Green/yellow