



La solution assistance



Liste codes erreur



Codes erreurs	Description
Ec	Défaut de communication
E1	Défaut de la sonde du réfrigérateur
E2	Défaut de la sonde du dégivrage
F1	Défaut de ventilation
dR	Défaut de l'interrupteur de la porte du réfrigérateur

SONDE REFRI		SONDE CGL	
T(°C)	Rcent(kΩ)	T(°C)	Rcent(kΩ)
-30	34.387	-30	34.080
-28	30.490	-28	30.218
-26	27.072	-26	26.830
-24	24.069	-24	23.854
-22	21.429	-22	21.237
-20	19.103	-20	18.932
-18	17.052	-18	16.900
-16	15.242	-16	15.105
-10	10.968	-10	10.870
-5	8.410	-5	8.335
0	6.499	0	6.441
1	6.178	1	6.123
2	5.875	2	5.822
3	5.588	3	5.538
4	5.317	4	5.269
5	5.060	5	5.015
6	4.817	6	4.774
7	4.587	7	4.546
8	4.370	8	4.331
10	3.969	10	3.933
15	3.135	15	3.107
20	2.494	20	2.471
25	1.997	25	1.979
30	1.610	30	1.596