



www.eurosav.eu

Part No.	Part Name	QTY	Unit
101	Top Panel	1	PC
102	Control Panel	1	PC
103	Control Panel Mounting	2	PC
104	Control Panel Mounting	2	PC
105	Control Panel Mounting	1	PC
106	Control Panel Mounting	1	PC
201	Top Panel Mounting	2	PC
202	Top Panel Mounting	2	PC
203	Top Panel Mounting	1	PC
204	Top Panel Mounting	1	PC
205	Top Panel Mounting	2	PC
206	Top Panel Mounting	2	PC
301	Upper Cutlery Tray	1	PC
302	Upper Cutlery Tray Rail	2	PC
303	Upper Cutlery Tray Rail	2	PC
304	Upper Cutlery Tray Rail	2	PC
305	Upper Cutlery Tray Rail	2	PC
306	Upper Cutlery Tray Rail	2	PC
307	Upper Cutlery Tray Rail	2	PC
308	Upper Cutlery Tray Rail	2	PC
309	Upper Cutlery Tray Rail	2	PC
310	Upper Cutlery Tray Rail	2	PC
311	Upper Cutlery Tray Rail	2	PC
313	Upper Cutlery Tray Rail	2	PC
314	Upper Cutlery Tray Rail	2	PC
315	Upper Cutlery Tray Rail	2	PC
316	Upper Cutlery Tray Rail	2	PC
401	Door Panel	1	PC
402	Door Panel Mounting	2	PC
403	Door Panel Mounting	2	PC
404	Door Panel Mounting	2	PC
405	Door Panel Mounting	2	PC
406	Door Panel Mounting	2	PC
408	Door Panel Mounting	2	PC
409	Door Panel Mounting	2	PC
411	Door Panel Mounting	2	PC
413	Door Panel Mounting	2	PC
414	Door Panel Mounting	2	PC
416	Door Panel Mounting	2	PC
415	Door Panel Mounting	2	PC
417	Door Panel Mounting	2	PC
418	Door Panel Mounting	2	PC
419	Door Panel Mounting	2	PC
420	Door Panel Mounting	2	PC
421	Door Panel Mounting	2	PC
421-1	Door Panel Mounting	2	PC
421-2	Door Panel Mounting	2	PC
421-3	Door Panel Mounting	2	PC
422	Door Panel Mounting	2	PC
423	Door Panel Mounting	2	PC
424	Door Panel Mounting	2	PC
425	Door Panel Mounting	2	PC
426	Door Panel Mounting	2	PC
427	Door Panel Mounting	2	PC
430	Door Panel Mounting	2	PC
431	Door Panel Mounting	2	PC
433	Door Panel Mounting	2	PC
434	Door Panel Mounting	2	PC
435	Door Panel Mounting	2	PC
436	Door Panel Mounting	2	PC
438	Door Panel Mounting	2	PC
501	Lower Cutlery Tray	1	PC
502	Lower Cutlery Tray Rail	2	PC
503	Lower Cutlery Tray Rail	2	PC
504	Lower Cutlery Tray Rail	2	PC
505	Lower Cutlery Tray Rail	2	PC
601	Lower Cutlery Tray	1	PC
602	Lower Cutlery Tray Rail	2	PC
603	Lower Cutlery Tray Rail	2	PC
604	Lower Cutlery Tray Rail	2	PC
605	Lower Cutlery Tray Rail	2	PC
606	Lower Cutlery Tray Rail	2	PC
609	Lower Cutlery Tray Rail	2	PC
608	Lower Cutlery Tray Rail	2	PC