


# **AGA SIX-FOUR CERAMIC HOTPLATE**


## ***SPARE PARTS MANUAL***

**LPRT 513156**


**DATE: OCTOBER 2003**




AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB)  
FRONT PLATE AND DOORS



AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB)  
ACCESSORIES/FURNITURE




AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB)  
INSULATION





AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB)  
 HOB CHASSIS ASSEMBLY






AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB) - UP TO M09-050  
 SPLASHBACK, CERAMIC HOTPLATE, FACIAS & HOB FRAME



LH Fascia - front




32 31 28 29 30




RH Fascia - front

**AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB) FROM M09-050  
 SPLASHBACK, CERAMIC HOTPLATE, FACIAS AND HOB  
 FRAME**



AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB)  
 TOP, BOTTOM, FAN AND GRILL ASSEMBLIES





AGA SIX-FOUR SERIES - DC6 (CERAMIC HOB)  
CHASSIS FRAME ASSEMBLY