



**AGA ELECTRIC (AIMS)
EE COOKER**


***SPARE PARTS
MANUAL***




AGA ELECTRIC AIMS - EE COOKER
 BASE, SIDES AND BACKPLATE




AGA ELECTRIC AIMS - EE COOKER
FRONT PLATE & DOORS




AGA ELECTRIC AIMS - EE COOKER
 TOP PLATE, INSULATING LIDS, SHROUD, WIRING ASSY




AGA ELECTRIC AIMS - EE COOKER
 OVENS, ACCESSORIES, SIMMERING PLATE, FAN ASSY




AGA ELECTRIC AIMS - EE COOKER
HOTSPOT, FIRE BARREL & CHAMBER ASSEMBLY



AGA ELECTRIC AIMS - EE COOKER
OVEN VENT FAN ASSEMBLY - UP TO M08-003



AGA ELECTRIC - AIMS COOKER
 OVEN VENTING FAN ASSEMBLY - FROM M08-003 TO M08-174



AGA ELECTRIC - AIMS COOKER
OVEN VENTING FAN ASSEMBLY - FROM M08-174