


**RAYBURN  
200SFW/212SFW  
COOKER**


***SPARE PARTS  
MANUAL***

**LPRT 513157**


**DATE: OCTOBER 2003**




**RAYBURN 200SFW/212SFW COOKER  
TOP/BOTTOM OVEN DOORS, FIRE DOOR & ASHPIT DOOR  
ASSEMBLIES**




**RAYBURN 200SFW/212SFW COOKER - UP TO M04-039  
HOB PLATE, INSULATING COVERS & FLUE CHAMBER**




**RAYBURN 200SFW/212SFW COOKER - FROM M04-039  
HOB PLATE, INSULATING COVERS & FLUE CHAMBER**




**RAYBURN 200SFW/212SFW COOKER  
FRONT PLATE, BACK & SIDE PLATE, BASE PLATE**



**RAYBURN 200SFW/212SFW COOKER  
BOILER, ASHPIT**



**RAYBURN 200/SFW/212SFW COOKER  
HOB PROTECTOR PLATE, TOP & WARMING PLATE**



**RAYBURN 200SFW/212SFW COOKER  
INSULATION & FIREBRICKS**