



No.	Part Name	BOM code	Quantity
1	cover, lamp	501112040033	1
2	holder, lamp	502409000055	1
3	thermostat knob	50111121000R	1
4	thermostat box	501111010071	1
5	thermostat	50240700000H	1
6	evaporator tray	501117600012	1
7	FZ shelf	503602010158	1
8	FF door shelf	503603010063	2
9	coping	501111210113	1
10	cabinet body	503705011036	1
11	top hinge	502905010177	1
12	FZ DOOR	503700112944	1
13	FF door seal	501113210025	1
14	bottom balcony	501113210044	1
15	top balcony	501113210045	2
16	FF door seal	501113210029	1
17	door	503700113097	1
18	centre hinge	502905000041	1
19	down hinge	502905010152	1
20	adjustable leg	501117600023	1

21	crisper	501113210016	1
22	cover, vegetable crisper	503603010064	1
23	compressor	501440210019	1
24			
25	suction tube	501607000110	1
26	fixed	501441000016	1
27	power cable	502401000418	1
28	protector starter	501440210019	1
29	pan, compressor assy		1
30	overload PTC		1
31	relay cover		1
32	dryer	501602000031	1