


CODE ERREUR	Description
EL	Défaut sonde de température
EH/EE	Problème afficheur

Valeurs sondes			
T (°C)	R (KΩ)	T (°C)	R (KΩ)
0	27,4936	16	14,1475
5	22,1835	18	13,0772
10	18,0151	20	12,0988
12	16,6048	22	11,2037
14	15,3198	25	10



La solution assistance